

### Installation Guidelines

---

#### Edge Trims - TA6 & TA8

(page 1 of 1) 01/01/21

**These installation guidelines apply to the following Gradus profiles only:**  
TA6 & TA8

1. It should be ensured that all surfaces to which the profile is to be fixed are dry, flat and free from any contaminants.
2. Cut the profile to the size required.
3. Apply a bead of Gradus Grip adhesive to the underside of the profile, then, ensuring the substrate is free from dust, firmly place the base into position. Please refer to separate Gradus Grip – Floor Trim Product Data Sheet for application details.

If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922 or fax on (+44)1625 425226