

Installation Guidelines

ET804 Square Edge Trim

Data Sheet: Page 1 of 1 15.05.18

This information applies to the following Gradus profiles:

(ACT48, ET210, ET210EBF4, ET212, ET212EBF4, ET804, ET804EBF4, ET805, ET805EBF4, ET806, ET806EBF4)

1. It should be ensured that all surfaces to which the profile is to be fixed are dry, flat and free from any contaminants.
2. Cut the profile to the size required.
3. Place the profile into position and through the pre-drilled holes, mark the substrate.
4. Drill the marked substrate using a 5mm drill bit and once drilled insert the appropriate sized plug. (5mm = yellow plug).
5. Apply a bead of proprietary cartridge adhesive to the underside of the profile, then, ensuring the substrate is free from dust, firmly place the base into position. *On timber subfloors, apply adhesive, and fix using No4 wood screws.
6. Secure in place using a No4 fixing screw.

If any further information is required, please do not hesitate to contact Gradus Technical Support on +44 (0)1625 428922