

Installation Guidelines

Stainless Steel Metal Skirting

Data Sheet: Page 1 of 1 15.05.18

This information applies to the following Gradus profiles:
(MSS790/8SF, MSS790/6SF)

Please read the following prior to installation of the metal skirting

1. Ensure that the substrate is dry, smooth and free from contaminants. Where a substrate is dusty it may be necessary to prime with a suitable primer.
2. Remove the protective film from the surface of the skirting.
3. Measure and cut the metal skirting to the required length using a proprietary blade for the material and cutting tool used.
4. Apply suitable cartridge adhesive to the back of the profile. Offer the profile to the wall and apply even pressure along the entire length to ensure full contact of the adhesive with the substrate.
5. To provide neat finishes to cut ends, pre-formed PVC-u internal and external corners along with end caps and joint junctions are recommended.

If any further information is required, please contact Gradus Technical Support on +44 (0)1625 428922