

Installation Guidelines

JC881025 & JC881050 Expansion Joint Covers

Data Sheet: Page 1 of 1 15.05.18

Note: Verify that the structural gap is in conformance with submittal data before beginning installation.

1. Install the architectural joint system on a level finished floor. This may require adding leveling compound on top of the substrate to provide a smooth mounting surface.

Figure 1

2. Cut the aluminum plates to the desired length.
3. Place the plates over the structural gap.
 - 3.1. For floor to floor condition, plate should be centered over the structural gap keeping the predrilled mounting holes on one side.
4. Mark the pre-drilled hole locations on the substrate.
5. Remove the plates.

Figure 1 (Floor to Floor shown)




Figure 2

6. Drill all marked holes on the substrate using a (8mm) drill bit and drill (60mm) deep.
7. Return the plates into position over the drilled hole locations and secure in place with Dia. 8mm (with M6 CSK screw) x 60mm 1g S/Steel sleeve anchor counter-sunk head HEX Drive (JCP Ref SLC08060SS)

Figure 2




Figure 3

8. Clean the exposed surfaces with a non-solvent cleaner as required.

Figure 3 (Completed installation)

